

## 200m2 Lecture Room Hearing Loop Kit

Part No. **AKL1**



### Overview

- Includes a PDA200E hearing loop amplifier, AMT tie/desk microphone, AML lectern microphone, 2 x APJ 3.5mm jack input plates, 2 x 6m Belden cable.
- Ideal for creating a high quality induction loop system for a Lecture room.
- Wall-mountable PDA200E amplifier capable of driving a perimeter loop of up to 200m2.
- Internal drive, level and metal compensation controls.
- Two balanced / unbalanced line level inputs.
- One microphone input with 12V phantom power for electret microphones.
- Full compatibility with the Outreach plate audio input extension system.
- Fully compliant with BS EN 60118-4 when correctly installed.
- Loop cable not included - our LOOP2W 1mm2 cable is suitable for most applications. If in doubt contact our technical department for advice.



### More Information

### Technical Specifications

Type	Wall mounting. Requires fixed Mains wiring.
Coverage	200m2 approx.
Mains supply	230V 50/60Hz.
Auxiliary inputs	1 Microphone and 2 x Line/Outreach screw connectors (on PDA200E).



Indicators	Input level; loop current meter (peak 3, 2, 1); compression; power on.
Controls	Input level; loop drive, metal compensation.
Product dimensions (mm)	W 271 x H 200 x D 77mm (amplifier only);
Construction & finish	White painted steel (PDA200E); plastic accessories.
IP Rating	IP20.
Weight	2.9 kg (amplifier only).
Operating conditions/temperature	-5°C to +40°C. Max relative humidity: 95%.
Kit contents	PDA200E 200m2 hearing loop amplifier; AMT tie/desk microphone, AML lectern microphone and 2 x APJ 3.5mm jack input plate; 2 x 6m Belden cable; Loop Fitted sticker. Loop cable IS NOT included.



T 01942 322744 E sales@c-tec.co.uk  
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom