

200m2 TV/Music Lounge Hearing Loop Kit

Part No. **AKT1**



Overview

- Includes a PDA200E hearing loop amplifier, AMP handheld microphone, APS SCART to double phono lead, APXM outreach plate, APL outreach plate, AL5 lead and 2 x 6m Belden cable.
- Ideal for creating a high quality induction loop system for a TV or Music lounge.
- Wall-mountable PDA200E amplifier capable of driving a perimeter loop of up to 200m2.
- Internal drive, level and metal compensation controls.
- Two balanced / unbalanced line level inputs.
- One microphone input with 12V phantom power for electret microphones.
- Full compatibility with the Outreach plate audio input extension system.
- Fully compliant with BS EN 60118-4 when correctly installed.
- Loop cable not included - our LOOP2W 1mm2 cable is suitable for most applications. If in doubt contact our technical department for advice



More Information

Technical Specifications

Type	Wall mounting. Requires fixed Mains wiring.
Coverage	200m2 approx.
Mains supply	230V 50/60Hz.
Auxiliary inputs	1 Microphone and 2 x Line/Outreach screw connectors (on PDA200E).



Indicators	Input level; loop current meter (peak 3, 2, 1); compression; power on.
Controls	Input level; loop drive, metal compensation.
Product dimensions (mm)	W 271 x H 200 x D 77mm (amplifier only);
Construction & finish	White painted steel (PDA200E); plastic accessories.
IP Rating	IP20.
Weight	2.9 kg (amplifier only).
Operating conditions/temperature	-5°C to +40°C. Max relative humidity: 95%.
Kit contents	PDA200E hearing loop amplifier; AMP handheld microphone, APS SCART lead, APXM XLR mic. level connector plate, APL dual phono line level connector plate, AL5 lead; 2 x 6m Belden cable; Loop Fitted



T 01942 322744 E sales@c-tec.co.uk
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom